HP StorageWorks DAT SCSI Tape Drives user guide



Part number: Q1573-90905 Second edition: February 2007

Legal and notice information

© Copyright 2005, 2007 Hewlett-Packard Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

 $Microsoft,\,Windows,\,Windows\,XP,\,and\,\,Windows\,\,NT\,\,are\,\,U.S.\,\,registered\,\,trademarks\,\,of\,\,Microsoft\,\,Corporation.$

UNIX is a registered trademark of The Open Group.

Contents

About	his guide
Inter	ded audience
	ed documentation
Doc	ment conventions and symbols
Proc	chnical support
Regi	tering your tape drive
Subs	ription service
HP v	ebsites
Doc	mentation feedback
1 Refo	re you start
HD	r <mark>e you start</mark>
Whi	h operating systems are supported?
How	do I connect the drive to my server?
Why	is the SCSI bus type importants
How	can I check the SCSI bus type and SCSI ID?15
Who	are the mounting requirements for an internal tape drive?
	Mounting bay
11-:	Mounting hardware
USIN	the HP StorageWorks Tape CD-ROM
2 Drive	rs and backup software
Insta	drivers
	nstalling on Windows
	Recommended install process, before connecting the tape drive
	Alternative install process, after connecting the tape drive
	nstalling on UNIX
ا ا	nstalling on IA64
Upg	ade backup software
3 Insta	ling an internal DAT tape drive
Che	k the drive's SCSI ID
Prep	rre mounting bay
Atta	h mounting hardware
	HP ProLiant servers
	Mounting rails
	Mounting screws
Insta	drive and connect power cable
Atta	h power and SCSI cables
	Where should the SCSI terminator be?
Secu	e the drive
	Aounting hardware used (HP ProLiant)
	No mounting hardware used
4.1.	le de la la companya de la companya
4 Instc	ling an external DAT tape drive
Che	k the drive's SCSI ID

	Connect the SCSI cable		. 31
5	Stalling a removable DAT tape drive Which rackmount systems can I use? Airflow requirements How do I connect the drive to my server? Install the drive Set the drive's SCSI ID Why does the tape drive need a terminator? Replacing the drive	 	33 33 34 35 36
6	erify installation		39
7	Pperating your tape drive Front panel LED sequences for the HP StorageWorks DAT 160 tape drive LED sequences for the HP StorageWorks DAT 72 and DAT 40 tape drive oading and unloading Inserting cartridges Removing cartridges Removing power from the drive	· · · · · · · · · · · · · · · · · · ·	. 44 . 45 . 45 . 46
8	se the correct media Data cartridges HP StorageWorks DAT 160 tape drives and HP DAT 160 cartridges Compatibility Write-protecting cartridges Cleaning cartridges Handling cartridges Getting the most out of cartridges and drives		47 47 47 48 48 48
9	Sing HP OBDR Compatibility What does HP OBDR do? Remote disaster recovery (ProLiant servers only) Esting for compatibility Running HP OBDR If restore fails	 	51 51 51 51 51
10	Diagnostic Tools and Performance Diagnostic tools	 	. 55 . 55 . 56
1	Troubleshooting General Procedure	 	. 58 . 58

12	Replacing an internal tape	e c	lri	ve																									61
	To disconnect your drive																												61
	To reconnect your tape drive																											•	61
1 2	SCSI configuration guide																												63
1 0	SCSI Configuration guide	•	•	•	•	•	•	•	•		•	•	•	•	•	•	•	•	•		•	•		•	•	•			
	SCSI in HP StorageWorks DAT device	es	•		•			•			•																	-	63
	SCSI terminology																												63
	Setting up the SCSI bus																												64
	SČSÍ ID numbers																												64
	Identifying SCSI IDs																												64
	Setting the SCSI ID on HP StorageW	'ork	s D	AΤ	dr	ives	s.																						65
	SCSI termination																												65
	Internal drives																												65
	External drives																												66
	Removable drives		•	•	•		•	•	•	•	•	•		•	•	•	•	•	•	•	•	•	•	•	•		•	•	67
	SCSI cables		•	•	•		•	•	•	•	•	•		•	•	•	•	•	•	•	•	•	•	•	•		•	•	68
																													68
	Cable length		•	•	•		•	٠	•	•	•	•		•	•	•	•	•	•	•	•	•	•	•	•		•	•	
	Cable quality		•	•	•		•	•	•	•	•	•		•	•	•	•	•	•	•	•	•	•	•	•		•		68
	With internal devices																												68
	With external devices .		•																										68
	With removable devices																												68
	Note on SE and LVD interfaces																												68

Figures

ı	Front view of HP StorageWorks DAT 160 tape drive	13
2	Front view of HP StorageWorks DAT 72 and 40 tape drive	14
3	Checking the SCSI ID	19
4	Removing cover from typical ProLiant server	21
5	Removing cover from typical AlphaServer	21
6	Attaching mounting rails	22
7	Attaching mounting screws	23
8	Installing tape drive	24
9	Connecting power and SCSI cables	25
10	Securing drive, mounting hardware used	26
11	Securing drive, no mounting hardware used	27
12	Setting the SCSI ID	29
13	Connecting the SCSI cable	31
14	Connecting the power cable	32
15	Extractor lever on tape drive fully open	34
16	Inserting the tape drive	35
17	SCSI address switch on tape array	36
18	Extractor lever in out position	37
19	Removing the tape drive	37
20	Front panel, HP StorageWorks DAT 160 external drive	41
21	Front panel, HP StorageWorks DAT 72 and DAT 40 external drive	42
22	Inserting a DAT 160 cartridge into an HP StorageWorks DAT 160 external drive	45
23	Ejecting a DAT 160 cartridge from an HP StorageWorks DAT 160 external drive	46
24	Write protecting a cartridge	48
25	Inserting cartridge for OBDR	52
26	Keeping eject button pressed down, power on in OBDR model	52
27	SCSI termination in internal drives	66
28	SCSI termination in external drives	67
29	SCSI termination in daisy-chained external drives	67

Tables

1	Document conventions													Ç
2	Supported SCSI bus types													15
3	Power requirements													16
4	LED sequences													43
5	Data cartridge compatibility													47
6	Cleaning cartridge compatibility													49

About this guide

This guide provides information about:

- Installing the HP StorageWorks DAT SCSI tape drive
- Using the HP StorageWorks DAT SCSI tape drive
- Troubleshooting the HP StorageWorks DAT SCSI tape drive

Intended audience

This guide is intended for users who install, operate and maintain the HP StorageWorks DAT tape drive.

Related documentation

In addition to this guide, the following document provides related information:

• 'Start here' poster for an overview of the installation information in this guide (available in English, French, German and Japanese)

You can find these documents from the Manuals page of the HP Business Support Center website:

http://www.hp.com/support/manuals

In the Storage section, click **Tape Storage and Media** and then select your product.

Document conventions and symbols

Table 1 Document conventions

Convention	Element
Blue text: Table 1	Cross-reference links and e-mail addresses
Blue, underlined text: http://www.hp.com	website addresses
Bold text	 Keys that are pressed Text typed into a GUI element, such as a box GUI elements that are clicked or selected, such as menu and list items, buttons, tabs, and check boxes
Italic text	Text emphasis
Monospace text	 File and directory names System output Code Commands, their arguments, and argument values
Monospace, italic text	Code variablesCommand variables
Monospace, bold text	Emphasized monospace text

△ WARNING!

Indicates that failure to follow directions could result in bodily harm or death.

△ CAUTION:

Indicates that failure to follow directions could result in damage to equipment or data.

IMPORTANT:

Provides clarifying information or specific instructions.

NOTE:

Provides additional information.

HP technical support

For worldwide technical support information, see the HP support website:

http://www.hp.com/support

Before contacting HP, collect the following information:

- Product model names and numbers
- Technical support registration number (if applicable)
- Product serial numbers
- Error messages
- Operating system type and revision level
- Detailed questions

Product warranties

For information about HP StorageWorks product warranties, see the warranty information website:

http://www.hp.com/go/storagewarranty

Registering your tape drive

Once you have installed and tested your HP StorageWorks Ultrium tape drive, please take a few minutes to register your product on the following website:

http://www.register.hp.com

To ensure your registration is complete, there are a number of questions on the electronic form that are mandatory. Other questions are optional. However, the more you feel able to complete, the better HP can meet your needs.

Subscription service

HP recommends that you register your product at the Subscriber's Choice for Business website:

http://www.hp.com/go/e-updates

After registering, you will receive e-mail notification of product enhancements, new driver versions, firmware updates, and other product resources.

After signing up, you can quickly locate your products by selecting **Business support** and then **Storage** under Product Category.

HP websites

For additional information, see the following HP websites:

- http://www.hp.com
- http://www.hp.com/go/storage
- http://www.hp.com/service_locator
- http://www.hp.com/support/manuals
- http://www.hp.com/support/downloads

Documentation feedback

HP welcomes your feedback.

To make comments and suggestions about product documentation, please send a message to storagedocs.feedback@hp.com. All submissions become the property of HP.


1 Before you start

HP StorageWorks DAT models

This guide describes how to install and operate the following HP StorageWorks DAT SCSI tape drive models:

- HP StorageWorks DAT 160
- HP StorageWorks DAT 72
- HP StorageWorks DAT 40

For a detailed product specification, please refer to our World Wide Web site (http://www.hp.com).



1. Clean LED


4. Ready LED

2. Tape LED

5. Eject button

3. Drive LED

Figure 1 Front view of HP StorageWorks DAT 160 tape drive



2. Tape LED

Figure 2 Front view of HP StorageWorks DAT 72 and 40 tape drive

Which operating systems are supported?

HP StorageWorks DAT SCSI drives can be connected to servers running under Windows®, NetWare, UNIX, Tru64, Linux and other major operating systems. Refer to the HP StorageWorks Tape Software Compatibility topic on our World Wide Web site (http://www.hp.com/go/connect/) for the most recent information about the operating system versions that are supported.

How do I connect the drive to my server?

The following quidelines apply:

- For optimum performance the drive should be the only device on the SCSI bus.
- Always terminate the SCSI bus.
- Do not attach the drive to the same SCSI bus as your disk drive or to a RAID controller (unless you
 are connecting to a ProLiant server with a Smart Array 6i RAID controller).

You will need a properly installed and configured SCSI host bus adapter (HBA) or a built-in SCSI controller on your server and a suitably-rated SCSI cable.

Why is the SCSI bus type important?

The SCSI bus type determines the speed at which data can be transferred between devices on the bus and the maximum length of cable that can be used. The drives support a burst transfer rate of 160 MB/sec. To benefit from this level of performance, it is important to ensure that the drives are connected to a SCSI bus of a similar or higher specification. This means that you need:

- An Ultra160 or Ultra320 SCSI bus. If you attach the drive to a lower specification SCSI bus, it will still work but data will not be transferred as quickly.
- LVD-rated SCSI cabling and terminators. The LVD interface enables the data to be transferred at the drive's maximum rate.

NOTE:

The drives are not compatible with high voltage differential (HVD) SCSI devices.

Table 2 Supported SCSI bus types

SCSI Bus Type	Supported
Ultra 160 LVD, Ultra 320 LVD	Yes. These are recommended configurations.
Ultra2 LVD, Ultra Wide LVD	Yes. These are supported, but performance may be impaired.
Ultra wide, single-ended	Yes. But this is not a recommended configuration as it will restrict performance.
Ultra narrow, single-ended	Yes. But this is not recommended as it will severely restrict performance and you will need a suitable cable or adapter.
High Voltage Differential	No. The drive will not work and you may damage the drive or controller

How can I check the SCSI bus type and SCSI ID?

For many operating systems, you can install and run HP Library & Tape Tools from either the HP StorageWorks Tape CD-ROM or http://www.hp.com/support/tapetools to check your server's current SCSI configuration (see also "Diagnostic tools" on page 55. This will provide information about the SCSI bus and the SCSI IDs in use.

What are the mounting requirements for an internal tape drive?

Mounting bay

You need one industry-standard, 51/4-inch, half-height bay in which to install the HP StorageWorks DAT tape drive. Power requirements are:

Table 3 Power requirements

Voltage	Typical	Current	Maximun	n Current
	DAT 160	DAT 72/40	DAT 160	DAT 72/40
5 V	1.54 A	0.7 A	1.61 A	0.8 A
12 V	0.26 A	0.3 A	1.3 A	1.0 A

Mounting hardware

For many servers, no mounting tray or rails are required. Devices simply slide into the server's chassis and are fixed with screws. Other servers have built-in trays or rails.

Rail kits for a number of industry-standard servers may be available. For more details refer to: http://www.hp.com/go/connect.

Some servers use non-standard mounting rails and do not include spares. If this is the case with your system, you will have to order these accessories from the server manufacturer before you can install the tape drive.

Using the HP StorageWorks Tape CD-ROM

The HP StorageWorks Tape CD-ROM is a central source of information about your tape drive with utilities for getting the best performance from your tape drive.

Use the HP StorageWorks Tape CD-ROM to check installation, as described in this guide, and to verify and troubleshoot performance after installation. It helps you to:

- Install your product, which includes access to drivers, an installation check, and performance information and tools
- Learn about your product
- Register your product
- Buy media online
- Troubleshoot with HP Library & Tape Tools.

2 Drivers and backup software

Install drivers

Installing on Windows

One driver is required in order to use HP StorageWorks DAT SCSI tape drives.

• **hpdat:** This is the tape driver that works with all HP DAT products. It is regularly updated and is available on the HP StorageWorks CD-ROM or on the HP Support web site.

The CD contains a driver install package for the following Microsoft Windows operating systems: Windows Server 2000, Windows Server 2003 and Windows XP. If you prefer to use Windows Device Manager to install the tape drivers manually, you will find them in the **drivers** directory on the CD-ROM.

IMPORTANT:

We strongly recommend that you use the installer package on the HP StorageWorks CD-ROM to install the drivers BEFORE you connect the tape drive.

Updates to the drivers may be provided from time to time on the HP support web site (http://www.hp.com/support). We recommend that these are installed after using the installer on the CD-ROM.

Recommended install process, before connecting the tape drive

- 1. Insert the StorageWorks CD
- Select the install drivers link.
- 3. Run the automated installer and follow the process to load the driver onto the system.
- 4. Once you have installed the tape drive and rebooted, as described in this guide, the tape drive will be detected automatically and the correct driver will be used.

Alternative install process, after connecting the tape drive

If you have not already installed drivers, the Windows Found New Hardware wizard may run when you power on the server and tape drive.

Either:

Follow the on-screen instructions to search for the required driver on the CD-ROM.

Or:

- 1. Cancel the wizard and insert the HP StorageWorks CD-ROM.
- 2. Select the install drivers link on the CD-ROM.
- 3. Run the automated installer and follow the process to load the driver onto the system.
- On completion of the installation the tape drive will be ready to use.

Installing on UNIX

The recommended backup applications use the operating system's standard, built-in device drivers. To upgrade drivers we recommend that you patch to the latest version of the operating system or configure

device files, as described in the *UNIX Configuration Guide* on the CD-ROM. This guide also describes how to verify installation.

MOTE:

The UNIX Configuration Guide also contains instructions for installing and verifying installation on Linux.

Installing on IA64

If you are installing on an IA64 system, such as an HP Integrity server, check http://www.hp.com/go/connect for the latest information on the availability of backup application upgrades and drivers.

Upgrade backup software

It is important to check http://www.hp.com/go/connect for software compatibility and install any recommended upgrades.

NOTE:

Certain backup applications require you to use their own Tape driver instead of the HP Ultrium Tape driver.

For optimum performance it is important to use a backup application that is appropriate for your system's configuration. In a direct attach configuration, where the tape drive is attached to a standalone server, you can use backup software that is designed for a single server environment. In network configurations you will need backup software that supports enterprise environments. HP, Symantec, Legato, Yosemite and Computer Associates all provide suitable products. Further details about these and other products that may be appropriate can be found on our connectivity web site.

- 1. Go to our connectivity web site: http://www.hp.com/go/connect and select tape backup.
- 2. Select software compatibility.
- 3. Select your combination of operating system and tape drive model in the table. A list of supported backup applications is displayed. This will also tell you whether your configuration is compatible with HP One-Button Disaster Recovery, HP OBDR. (All HP StorageWorks DAT tape drives support HP OBDR. However, you can only use this feature if your system configuration and backup application also support it. See "Using HP OBDR" on page 51.)
- 4. Make sure you have a backup application that supports HP StorageWorks DAT tape drives and download any upgrades or patches, if required.

3 Installing an internal DAT tape drive

If you are installing an external DAT tape drive, please refer to "Installing an external DAT tape drive" on page 29.

If you are installing a removable DAT tape drive, please refer to "Installing a removable DAT tape drive" on page 33.

Check the drive's SCSI ID

Your HP StorageWorks DAT drive is shipped with a default SCSI ID of 3. Each device on the SCSI bus must have an unique SCSI ID number. The drive can be assigned any *unused* ID between 0 and 15. Do not use SCSI ID 7, which is reserved for the SCSI controller. SCSI ID 0 is typically assigned to the boot disk and should also not be used unless the tape drive is on a dedicated SCSI bus.

△ CAUTION:

Static electricity can damage electronic components. Always wear an antistatic wriststrap if possible. If not, to equalize the electromagnetic charges, touch a bare metal part of the server (such as the back plate) before you remove the tape drive from its bag.




Figure 3 Checking the SCSI ID

1. Determine whether you need to change the SCSI ID from the default of 3.

For many operating systems you can install and run HP Library & Tape Tools from the HP StorageWorks Tape CD-ROM to check your server's current SCSI configuration (see "HP Library & Tape Tools" on page 55). This will provide information about the SCSI bus and the SCSI IDs in use.

The UNIX Configuration Guide on the HP StorageWorks Tape CD-ROM also contains instructions on how to determine the SCSI IDs of existing devices on UNIX servers.

2. Change the tape drive's SCSI ID, if necessary.

The SCSI ID is set using jumpers on a set of pins at the rear of the drive, as shown in figure 3. Use tweezers or small pliers to move the jumpers to the pattern corresponding to the ID you want. Do not remove the TP jumper. It should always be set.

MOTE:

Spare jumpers will be attached to the drive. The drive is supplied with compression enabled. It can be disabled by removing the compression jumper, but this is not generally recommended. For further details, refer to the *UNIX Configuration Guide* on the HP StorageWorks Tape CD-ROM.

Prepare mounting bay

△ CAUTION:

To avoid personal injury or damage to the server or tape drive, ensure that the server is disconnected from the mains power supply while you install the drive.

- 1. Assemble the necessary tools and materials:
 - Phillips screwdriver
 - Flat-bladed screwdriver (if your server uses slotted screws)
 - Torx screwdriver (if your server uses torx screws)
 - Your server manuals (for reference during installation)
- Perform a normal system shutdown and turn off the server and any connected peripherals.
- Remove the cover and front panel from the server, as detailed in your server's documentation.

As you work inside the server, you may have to disconnect other signal cables or power cables from other devices to maneuver the new drive into place. If you have to do this, make a note of their position and connections so you can put them back correctly later.




Figure 4 Removing cover from typical ProLiant server




Figure 5 Removing cover from typical AlphaServer

- **4.** Remove the filler panel from a spare 51/4-inch bay of your server, as described in your server's documentation. Keep any screws for use in "Secure the drive" on page 26.
- 5. You are now ready to install your tape drive.

Attach mounting hardware

If your server requires special rails or other hardware to install the tape drive, mount them on the tape drive now. If your server does not require special mounting hardware, proceed to "Install drive" on page 24 now.

△ CAUTION:

Static electricity can damage electronic components. Always wear an antistatic wriststrap if one is available. If not, after you have disconnected power from the server and removed the cover, touch a bare metal part of the chassis. Similarly, touch a bare metal part of the drive before installing it.

HP ProLignt servers

NOTE:

If mounting hardware is supplied with your tape drive, it may not be exactly the same as shown in the illustrations.

Different models of server require different mounting methods. The server may also incorporate a locking mechanism to hold the tape drive in place. See "Secure the drive" on page 26.

Please check your HP ProLiant server documentation to ascertain the correct method of mounting, and to check whether mounting hardware is provided with the server.

Mounting rails

Some HP ProLiant servers, such as ML530 and ML570, require mounting rails. These may be metal or plastic rails attached to the filler panel of the server's drive bay.

Use a regular Phillips screwdriver to attach the appropriate rails. Use the M3 screws provided with the tape drive, as shown in Figure 6 on page 22.

Ensure you do use the M3 screws provided. The rails may be attached to the filler panel by screws of a different thread/size type and these should not be used. If in doubt, refer to your HP ProLiant server documentation.





Figure 6 Attaching mounting rails

Mounting screws

Other HP ProLiant server models, such as ML350 and ML370, only require the use of special locating screws with no mounting rail.

Use a Torx screwdriver to attach the appropriate screws. You may need to purchase the M3 screws separately. Position the screws, as shown in Figure 7 on page 23.

- HP ProLiant ML350: Use M3 mounting screws. These have a thicker head than the standard M3 screws.
- HP ProLiant ML370: Use M3 offset mounting screws. These have a thick offset piece and a thicker head than the standard M3 screws.



- 1. M3 mounting screws
- 2. M3 offset mounting screws

Figure 7 Attaching mounting screws

Other servers

Attach the appropriate mounting hardware. Refer to the manufacturer's documentation for instructions.

- If you are installing on a server that requires a tray, place the tape drive in the tray.
- If you are installing in a server that requires mounting rails, fasten the rails to the tape drive.
- Some servers have snap-on mounting rails attached to the filler panel. These can be removed and attached to the tape drive with screws.

Install drive and connect power cable

Slide the tape drive into the open bay, aligning the tray or rails with the slots in the bay, as shown in Figure 8 on page 24.




Figure 8 Installing tape drive


If your server does not use mounting hardware, check that the holes in the chassis are aligned with the holes in the side of the tape drive.

Do not secure the drive at this point because you may have to move the drive to get the cables into place.

Attach power and SCSI cables

To support the high performance of the tape drive it is important that you connect to a recommended SCSI bus and use a suitably-rated SCSI cable, see "Why is the SCSI bus type important?" on page 14.

- Check your server or HBA documentation to ensure that the SCSI bus and cabling supports up to Ultra 160 bus speeds. We recommend that you attach the SCSI ribbon cable supplied with the tape drive to the SCSI host bus adapter.
- 2. Attach a spare power cable from the server's internal power supply to the power connector, as shown in Figure 9 on page 25.
- 3. Attach a spare connector on the server's built-in SCSI bus or HBA's SCSI ribbon cable to the SCSI connector of the drive, as shown in Figure 9 on page 25.
- 4. If the drive is the last device on the SCSI chain, make sure that the SCSI cable is terminated correctly.



2 and 4. power cable

6. SCSI controller

3. tape drive

Figure 9 Connecting power and SCSI cables

Where should the SCSI terminator be?

Termination must be present at two and ONLY two positions on the SCSI bus—at the beginning of the SCSI bus and at the end of the SCSI bus. Termination is normally enabled by default on the HBA and most internal SCSI cables have a terminator attached. This will usually be a small, rectangular block of plastic attached to the cable end and marked 'SCSI Terminator'.

Therefore, assuming the HBA is the first device on the bus, you should check that the second terminator is placed after the last device, as shown in Figure 9 on page 25, item 1.

Secure the drive


MOTE:

The server latches and side views of your server model may not be exactly the same as shown in the illustrations. Please refer also to you server documentation.

Mounting hardware used (HP ProLiant)

Ensure that you use the correct mounting rails or locating screws, as described in "Attach mounting hardware" on page 22. The server also incorporates a locking mechanism to hold the tape drive in place.

1. Push the server latch down to lock the tape drive into position, as shown in Figure 10 on page 26.




- 1. plastic rail
- 2. server latch

Figure 10 Securing drive, mounting hardware used

2. Ensure blanking plates are in place over empty bays and replace the cover on the server.

No mounting hardware used

1. Use the M3 screws provided with the tape drive. Check that the holes in the chassis are aligned with the holes in the sides of the drive and use a regular Phillips screwdriver to secure the M3 screws, as shown in Figure 11 on page 27.



1. M3 screws, supplied with tape drive

Figure 11 Securing drive, no mounting hardware used

2. Ensure blanking plates are in place over empty bays and replace the cover on the server.

4 Installing an external DAT tape drive

If you are installing an internal DAT tape drive, please refer to "Installing an internal DAT tape drive" on page 19.

If you are installing a removable DAT tape drive, please refer to "Installing a removable DAT tape drive" on page 33.

Check the drive's SCSI ID

Your HP StorageWorks DAT drive is shipped with a default SCSI ID of 3. Each device on the SCSI bus must have an unique SCSI ID number. The drive can be assigned any *unused* ID between 0 and 15. Do not use SCSI ID 7, which is reserved for the SCSI controller. SCSI ID 0 is typically assigned to the boot disk and should also not be used unless the tape drive is on a dedicated SCSI bus.




Figure 12 Setting the SCSI ID

1. Determine whether you need to change the SCSI ID from the default of 3.

For many operating systems you can install and run HP Library & Tape Tools from the HP StorageWorks Tape CD-ROM to check your server's current SCSI configuration (see "Diagnostic tools" on page 55). This will provide information about the SCSI bus and the SCSI IDs in use

The UNIX Configuration Guide on the HP StorageWorks Tape CD-ROM also contains instructions on how to determine the SCSI IDs of existing devices on UNIX servers.

2. Change the tape drive's SCSI ID, if necessary.

Use a small screwdriver or a ball-point pen to press the indented SCSI ID selector buttons on the rear panel (see Figure 13 on page 31) until the required value is displayed. Do not use a pencil because small bits of graphite could contaminate the drive.

MOTE:

The computer and the tape drive SCSI IDs are only checked at power-on. To change the SCSI ID after installation, power down both the computer and the tape drive, change the drive's SCSI ID, power up the tape drive, and then power up the computer.


Connect the SCSI cable

A wide VHD-to-HD SCSI cable and LVD terminator are provided to connect your HP StorageWorks DAT tape drive to a VHD SCSI port on an LVD SCSI bus. If your server has an HD SCSI port, you must either purchase and install a VHD-to-HD adapter or use an HD-to-HD cable instead of the supplied cable. Refer to our web site for recommended products: http://www.hp.com/go/connect.

\triangle CAUTION:

To avoid damaging the computer or tape drive, ensure that both are powered off while you attach the SCSI cable.

- 1. Make sure you are connecting to a recommended SCSI bus type. See "Why is the SCSI bus type important?" on page 14. Do not connect the tape drive to the same bus as a RAID controller. For optimum performance, we recommend that your HP StorageWorks DAT drive is installed on a dedicated SCSI bus. If it is not, do not connect it to the same bus as your disk drive.
- 2. Perform a normal system shutdown and turn off the server and any connected peripherals.
- Attach the VHD connection on the SCSI cable to the server's external SCSI connector and secure it by tightening the screws.



LVD SCSI terminator

Figure 13 Connecting the SCSI cable

- 4. Attach the HD connection on the SCSI cable to one of the SCSI connectors on the rear panel of the tape drive and secure it by tightening the screws.
- 5. Connect the LVD terminator to the drive's other SCSI connector and tighten the screws to secure it.

Why does the tape drive need a terminator?

Terminators are essential, as they provide the correct voltages on the SCSI bus and prevent unwanted signal reflections from interfering with data transfers. The rule is:

There must be termination at both physical ends of the bus and only at the ends.

Normally the HBA forms one end of the SCSI bus and provides termination. You, therefore, need to ensure that the other end of the bus is terminated. If the tape drive is at the end of the SCSI bus, the terminator must be attached to the tape drive.


If you want to attach additional devices to the SCSI bus after the tape drive, you will need to remove the SCSI terminator and attach the next device to this SCSI connector. Make sure that you attach the terminator to the last device in the chain.

Always use an LVD terminator (supplied with the tape drive) or a multimode terminator. See "SCSI termination" on page 65 for more information about SCSI cables and termination.

Connect the power cable

An external HP StorageWorks DAT drive will operate using any voltage in the range 100–240 volts (0.7 A, 50-60 Hz). No adjustment is needed. To connect your drive to the power supply, proceed as follows:

- 1. Make sure that the drive is switched OFF (O side down). The power switch is on the rear panel.
- 2. Plug the power cable securely into the socket on the rear panel of the drive.
- Plug the other end of the power cable into the power outlet.



1.power socket

2 power on/off switch

Figure 14 Connecting the power cable

5 Installing a removable DAT tape drive

If you are installing an internal DAT tape drive, please refer to "Installing an internal DAT tape drive" on page 19.

If you are installing an external DAT tape drive, please refer to "Installing an external DAT tape drive" on page 29.

Which rackmount systems can I use?

HP StorageWorks DAT removable tape drives are used in conjunction with the HP Tape Array 5300 system, which can be used with both full-height and half-height tape drives. It will hold up to four HP StorageWorks DAT tape drives. The tape array is designed to be installed into HP, IBM and other compatible 19" rackmount systems. It must be properly installed and configured. Refer to your tape array documentation for further details.

Airflow requirements

The HP Tape Array 5300 is designed to provide adequate airflow for up to four half-height or up to two full-height tape drives. As long as the tape array is fully populated, it will provide adequate airflow for your HP StorageWorks DAT tape drives. If you have unused bays in the tape array, you must install the blanking plates provided with the tape array. This ensures that there is adequate airflow to the drives. See the documentation with the tape array for details on installing blanking plates.

You should ensure that ventilation is adequate at the front and rear of the tape array.

How do I connect the drive to my server?

The following guidelines apply:

- For optimum performance the drive should be the only device on the SCSI bus.
- If you daisy-chain devices, make sure that devices are of the same SCSI type and that each device
 on the same SCSI bus has a unique SCSI ID and is terminated appropriately. Do not daisy-chain
 more than two devices on the same SCSI bus (for example, two LVD Wide Ultra drives).
- Always terminate the SCSI bus.
- Do not attach the drive to the same SCSI bus as a your disk drive or to a RAID controller.

The individual tape drives are connected to their host server via the high density LVD/SE SCSI connectors on the back of the tape array. They do not require any SCSI cables to plug into the tape array. However, suitably-rated cabling and terminators are required to connect the tape array with the SCSI host.


MOTE:

HP StorageWorks DAT removable drives do not have termination power enabled, termination must be supplied by the host.

Install the drive

HP StorageWorks DAT removable tape drives are designed to be installed in a rack-mounted HP Tape Array 5300. Refer to the documentation supplied with your tape array for tape array installation instructions.

 Before installing a tape drive, make sure that the extractor lever is in the fully open position (pulled out).



1. extractor lever, open

Figure 15 Extractor lever on tape drive fully open

△ CAUTION:

When handling a tape drive, hold the drive by the side carrier framework. To avoid possible damage, do not hold the body of the drive and do not push or pull on the tape drive's front panel.

2. Slide the tape drive into one of the open bays, ensuring that the guide rails on both sides of the drive locate into the slots on the partition wall. Carefully but firmly ensure the tape drive is pushed fully in so that the rear connectors are securely seated. The extractor level will close slightly.

MOTE:

Correct alignment of SCSI tape drives in the tape array is essential to ensure a secured connection is made between the interface of the drive and the interface of the array.

3. Push on the extractor lever to complete the insertion and to lock the tape drive in place.




Figure 16 Inserting the tape drive

4. If there are empty bays, insert a blanking plate. This is essential to ensure adequate airflow is maintained. Failure to do so may affect tape drive performance.

Set the drive's SCSI ID

To set the tape drive's SCSI ID you need to set the appropriate switch on the rear of the tape array. The number of address switches corresponds to the number of tape drives that can be inserted into the tape array.

Each device on the SCSI bus must have a unique SCSI ID.

- For HP ProLiant servers where the tape drive is connected to the built-in SCSI bus, we recommend that the tape drive is assigned a SCSI ID between 1 and 6.
- For all other servers and when used with separate HBAs, it can be assigned any unused ID between 0 and 15. Do not use SCSI ID 7, which is reserved for the SCSI controller. SCSI ID 0 is typically assigned to the boot disk and should also not be used unless the tape drive is on a dedicated SCSI bus.

Typically, the HP Tape Array may hold up to four tape drives where each drive is attached to a separate server. Under this configuration, the SCSI IDs of each tape drive will not conflict with each other as they are each installed onto a separate SCSI bus.

However, if you daisy-chain devices make sure that the devices are of the same SCSI type and that each device on the same SCSI bus has a unique SCSI ID. Do not daisy-chain more than two devices on the same SCSI bus and make sure that the end device is terminated.

Decide which SCSI ID to use.

For many operating systems you can install HP Library & Tape Tools from the HP StorageWorks Tape CD-ROM and run the "Install Check" to check your computer's current SCSI configuration (see "Diagnostic tools" on page 55). This will provide information about the SCSI bus and the SCSI IDs in use. The UNIX Configuration Guide on the HP StorageWorks Tape CD-ROM, also provides instructions on how to determine the SCSI IDs of existing devices.

2. Set the appropriate switch. Figure 5 shows the address switch on the back panel of the HP Tape Array 5300.




Figure 17 SCSI address switch on tape array

- 3. The HP Tape Array 5300 has four SCSI ID switches to enable the installation of up to four half-height drives.
- Make sure that a SCSI terminator is attached to the appropriate SCSI-OUT connector on the back of the tape array.
- 5. Determine whether you need to change the SCSI ID from the default of 3.

Why does the tape drive need a terminator?

Terminators are essential, as they provide the correct voltages on the SCSI bus and prevent unwanted signal reflections from interfering with data transfers. The rule is:

There must be termination at both physical ends of the bus and only at the ends.

Normally the HBA forms one end of the SCSI bus and provides termination. You, therefore, need to ensure that the other end of the bus is terminated. Attach the terminator to the appropriate SCSI-OUT connector on the tape array.

Replacing the drive

HP StorageWorks DAT removable drives can be removed and replaced without powering down the tape array. However you should be aware of the following:

- If all drives in the tape array are powered up when the system is turned on, the host will be aware of those drives. You can remove any of those drives and replace it with another drive as long as there is no activity on the bus.
- Do not remove or add drives to a bus that already has drives connected and running, for example backing up or restoring data. Wait until there is no activity on the bus before removing or adding drives.
- If a drive is not powered up or you place a drive in an empty slot after the system has been powered up, the system will have to be reset before the host will recognize the drive.
- The SCSI IDs are controlled by the tape array, not by the drives themselves, so if you remove a drive and replace it with another the ID will not change.
 - 1. Pull the extraction lever of the drive that you want to replace so that it is in the out position.




Figure 18 Extractor lever in out position

2. Using the extraction lever, pull the drive gently and firmly out of the tape array.




Figure 19 Removing the tape drive

3. To insert another drive, follow the instructions in "Install the drive" on page 34.

6 Verify installation

Once you have installed the drive hardware, check that drivers have been installed correctly and you have the correct version of backup software, and verify that the tape drive is functioning properly before you store your valuable data.

- 1. Switch on the drive and the server.
- 2. The tape drive will run its hardware self-test, which takes about 5 seconds. At the end of the hardware self-test:
 - **HP StorageWorks DAT 160 drives:** If self-test passes, the green Ready LED flashes and then shows steady green. If the test fails, the Drive Error and Tape Error LEDs flash, while the Ready and Clean (or Use Cleaning Cartridge) LEDs are off. This continues until the drive is reset.
 - All other drives: If self-test passes, both front panel lights should be off. If a hard error causes the self-test to fail, the clean light changes to steady amber.

See "Front panel" on page 41 for more information about front panel lights.

Installing drivers (Windows)

HP recommends that you install drivers before you install the tape drive, see "Install drivers" on page 17. If you have not already installed drivers, the Windows Found New Hardware wizard may run when you power on your tape drive and server. Follow the onscreen instructions to search for the required driver on the HP StorageWorks Tape CD-ROM. Or cancel the wizard and run the driver installation package, as described in "Alternative install process, after connecting the tape drive" on page 17.

Installing drivers (Unix)

To upgrade drivers we recommend that you patch to the latest version of the operating system or configure device files, as described in the *UNIX Configuration Guide* on the CD-ROM. See also "Installing on UNIX" on page 17.

MOTE:

Certain backup applications require you to use their own Tape driver instead of the HP Ultrium Tape driver.

- 3. Verify that the tape drive installation was successful.
 - For many operating systems you can run HP Library & Tape Tools from the HP StorageWorks CD-ROM. See also "Diagnostic Tools and Performance" on page 55 for more information about HP Library & Tape Tools, HP's free diagnostics and troubleshooting software.
 - If you encounter a problem during this verification procedure, turn to "Troubleshooting" on page 57 for help in diagnosing and fixing the problem.
- 4. You are now ready to carry out a backup and restore test to check that the drive can write data to tape. Use a blank cartridge. Windows Backup or Unix native backup applications can be used to check basic tape drive operation, but they will not support all the advanced features of your tape drive. We recommend that you upgrade your software application before running this test. Check http://www.hp.com/go/connect for software compatibility and install any recommended upgrades.

7 Operating your tape drive

Front panel




Figure 20 Front panel, HP StorageWorks DAT 160 external drive




Figure 21 Front panel, HP StorageWorks DAT 72 and DAT 40 external drive

LED sequences for the HP StorageWorks DAT 160 tape drive

The meaning of different patterns of LEDs is as follows:

Table 4 LED sequences

LED Sequence	Cause	Action required		
All LEDs OFF.	Drive may not have power, may be faulty or may have been power cycled or reset during a firmware upgrade.	Make sure the drive is switched on. The power on/off switch incorporates a green LED. If this is not on, check the power cable connection and replace the cable if necessary. You can use the power cable from your monitor or another device to check that the connection is working. If the power supply is present and all LEDs remain off, power cycle or reset the drive. If it still fails, call for service.		
Ready is ON.	The drive is ready for operation.	None. This is normal.		
Ready FLASHES.	The drive is carrying out a normal activity (read, write).	None. If the drive is upgrading firmware, do not reset or power cycle it.		
then Ready FLASHES- steady ON- FLASHES.	The drive is in OBDR mode.	See "Running HP OBDR" on page 52 for further details.		
-\(\) \(\) \(\) \(\) \(\) \(\) \(\) \(\)	The drive requires cleaning.	Load the DDS cleaning cartridge. See "Cleaning cartridges" on page 48 for supported cartridges and instructions. If the Clean LED is still flashing when you load a new or known good data cartridge after cleaning, call for service.		
Ready FLASHES and Clean is ON.	Cleaning is in progress.	None. The cleaning cartridge will eject on completion. The cleaning cycle can take up to 5 minutes to complete.		
Tape FLASHES.	The drive believes the current tape or the tape just ejected is faulty.	Unload the tape cartridge. Make sure that you are using the correct format cartridge. (See "Use the correct media" on page 47.) Reload the cartridge. If the Tape LED still flashes or starts flashing during the next backup, load a new or known good cartridge. If the Tape LED is now off, discard the 'suspect' tape cartridge. If it is still on, call for service.		

LED Sequence	Cause	Action required
Drive FLASHES.	The drive mechanism has detected an error.	Load a new cartridge. If the error persists, power cycle or reset the drive. If the Drive LED remains on, call for service.
Drive, Tape and Ready FLASH.	There is a firmware download problem.	Insert a cartridge to clear the LED sequence. If the condition persists, call for service.


LED sequences for the HP StorageWorks DAT 72 and DAT 40 tape drive

There are two LEDs, labeled Tape and Clean. The meaning of different patterns of LEDs is as follows:

	Tape LED	Clean LED	Meaning
00	on	off	The cartridge is loaded and the drive is ready.
-\(\)-	flashing slowly	off	The cartridge is loading or unloading, or self-test is in progress.
	flashing rapidly	off	The cartridge is loaded, activity is occurring.
	off or flashing	on	This is the Error Condition Signal. HP StorageWorks DAT drives perform a comprehensive self-test during power-up. If a hard error causes the self-test to fail, the clean light changes to steady amber. Run HP Library & Tape Tools to help diagnose the problem.
○ - \	off or flashing	flash- ing slowly	 This is the Media Caution Signal. Wait for the current operation to finish, then insert a different tape and repeat the operation that was being performed. If the media caution signal does not show this time, it indicates that the original cartridge was nearing the end of its useful life. Copy any data you want to keep from the original tape onto a new tape if possible, then discard the old tape. If the media caution signal appears again with the second tape, the tape heads need cleaning. If the media caution signal appears after using a cleaning cartridge, the cleaning cartridge has probably expired and should be discarded.
-\(\)-\(\)-	flashing slowly	flash- ing slowly	When the two LEDs flash alternately, the tape drive is in disaster recovery mode, restoring the operating system (see "Running HP OBDR" on page 52).

Loading and unloading

Inserting cartridges



- 1. cartridge slot
- 2. arrow indicates leading direction

Figure 22 Inserting a DAT 160 cartridge into an HP StorageWorks DAT 160 external drive

 Insert a cartridge into the slot on the front panel. As the cartridge is inserted, the drive takes it and performs a load sequence.

NOTE:

The illustration shows a DAT 160 cartridge. These cartridges are wider than earlier-format DDS cartridges and can only be used with HP StorageWorks DAT 160 tape drives. See "Data cartridges" on page 47 for more information about tape drive and cartridge compatibility.


- 2. **HP StorageWorks DAT 160 tape drives:** The Ready light flashes green while the drive performs its load sequence. When the cartridge is loaded, the Ready light shows steady green.
 - **HP StorageWorks DAT 72 and 40 tape drives:** The Tape light flashes green while the drive performs its load sequence. When the cartridge is loaded, the Tape light shows steady green.

Removing cartridges

△ CAUTION:

Never try to remove a cartridge before it is fully ejected.

1. Press the Eject button on the front panel.



1. eject button

Figure 23 Ejecting a DAT 160 cartridge from an HP StorageWorks DAT 160 external drive

2. The drive completes any task it is currently performing, winds the tape to the beginning, and ejects the cartridge. The sequence will take about 25 seconds for a write-enabled cartridge and 10 seconds for a write-protected cartridge.

Removing power from the drive

To ensure reliable operation, do not remove power from the drive during read, write, fast-search, load and unload activities.

8 Use the correct media

For best performance we recommend HP branded media. Order online at: http://www.hp.com/go/storagemedia. If you do not have internet access, refer to the User's Guide on the HP StorageWorks Tape CD-ROM for ordering information for tape cartridges and cleaning cartridges.

Data cartridges

HP StorageWorks DAT 160 tape drives and HP DAT 160 cartridges

HP DAT 160 cartridges (C8011A) can only be used with HP StorageWorks DAT 160 tape drives; they are wider than earlier formats and will not fit into earlier tape drive models. DAT 160 cartridges provide optimum performance and maximum capacity for HP StorageWorks DAT 160 tape drives. DAT 160 tape drives are also backwards compatible with some earlier formats, see Table 5 on page 47.

Compatibility

For optimum performance and storage capacity, use tape cartridges that match your drive's format, and normally use only one cartridge per day. Ideally, use:

- HP's DAT 160 cartridges with DAT 160 tape drives
- HP's DAT 72 cartridges with DAT 72 tape drives
- HP's DDS-4 cartridges with DAT 40 tape drives

Although HP StorageWorks DAT tape drives are fully backward compatible, old tape formats are more abrasive than later generations and using older tape formats can reduce the life expectancy of the tape drive. The compatibility between drive models and cartridges is summarized in Table 5 on page 47. Shaded boxes show the recommended media for each tape drive. Capacities assume a compression ration of 2:1.

Table 5 Data cartridge compatibility

	DDS-2 120 meter	DDS-3 125 meter	DDS-4 150 meter	DAT 72 170 meter	DAT 160 170 meter
HP StorageWorks DAT 160	not supported	not supported	read/write	read/write	160 GB* C8011A
HP StorageWorks DAT 72	not supported	read/write	read/write	72 GB* C8010A	not supported
HP StorageWorks DAT 40	read/write	read/write	40 GB* C5718A	not supported	not supported
* Capacity assumes 2:1 compression.					

MOTE:

DDS-1 cartridges are not supported on any HP StorageWorks DAT drive.


Write-protecting cartridges

If you want to protect the data on a cartridge from being altered or overwritten, you can write-protect the cartridge.

Always remove the cartridge from the tape drive before you change the write protection.

- To write-protect a cartridge, slide the tab on the rear of the cartridge so that the recognition hole is open.
- To write-enable a cartridge, slide the tab back so that the hole is closed.

Write-protection will not protect your cartridges against magnets (or bulk erasers).



- 1. tab closed, cartridge write-enabled
- 2. tab open, cartridge write-protected

Figure 24 Write protecting a cartridge

Cleaning cartridges

HP recommends weekly cleaning of the tape drive using an HP cleaning cartridge. There are two types of cleaning cartridges; you must use a DAT 160 cleaning cartridge with DAT 160 tape drives, see Table 6 on page 49.

Table 6 Cleaning cartridge compatibility

Tape drive model	Cleaning cartridge required
HP StorageWorks DAT 160 tape drives	You must use a DAT 160 cleaning cartridge, part number C8015A
All other HP StorageWorks DAT tape drives	You must use a standard cleaning cartridge, part number C5709A

Do not use swabs or other means of cleaning the heads. The cleaning cartridge uses a special tape to clean the tape heads. A cleaning cartridge can only be used 50 times or as instructed on the cartridge packaging. Always place a check mark in a box each time you use the cartridge to clean the drive. Replace the cleaning cartridge when all the boxes are checked. New cleaning cartridges are available from HP.

 Insert a cleaning cartridge into the drive. The tape drive automatically loads the cartridge and cleans the heads.

At the end of the cleaning cycle, the drive ejects the cartridge. The cleaning cycle takes approximately 30-60 seconds.

HP StorageWorks DAT 72 and DAT 160 drives: If the cleaning cartridge is not ejected, it has probably expired. In this case, press the Eject button, discard the cleaning cartridge and repeat the operation with a new one.

HP StorageWorks DAT 40 drives: If the cleaning cartridge ejects in less than 20 seconds, it has probably expired. In this case, discard the cleaning cartridge and repeat the operation with a new one.

2. Remove the cleaning cartridge from the drive.

The drive's TapeAlert feature will send a message to your backup application when the tape heads need cleaning or a cleaning cartridge has expired.

Handling cartridges

- Do not touch the tape media.
- Do not attempt to clean the tape path or tape guides inside the cartridge.
- Do not leave cartridges in excessively dry or humid conditions. Do not leave cartridges in direct sunlight or in places where magnetic fields are present (for example, under telephones, next to monitors or near transformers).
- Do not drop cartridges or handle them roughly.
- Do not stick more than one label onto the cartridge label area; extra labels can cause the cartridges to jam in the drive. Stick labels onto the label area only.
- See the insert included with the tape cartridge for storage conditions.

Getting the most out of cartridges and drives

- Use mostly the matching media type (DAT 160 media for HP StorageWorks DAT 160, DAT 72 media for HP StorageWorks DAT 72, DDS-4 media for HP StorageWorks DAT 40).
- Use media for the recommended number of times (DAT 160, DAT 72 and DDS-4=100 full backups). Overuse of the tape will cause it to degrade and possibly shed tape debris in the drive.
 Too many new tapes can also cause wear of the drive as they are rougher than used ones.
- Do not verify (DDS does read-after-write checking automatically).
- Do not overload the server during backups. Maximize the transfer rate (run overnight with no other processes) and use incremental backups if convenient.
- Do not overuse your tape drive—it is designed for approximately three hours of tape pulling per day, not constant usage—and clean the drive regularly. See "Cleaning cartridges" on page 48.



9 Using HP OBDR

Compatibility

HP One-Button Disaster Recovery is a standard feature on all HP StorageWorks DAT tape drives. However, it can only be used with specific configurations and will only recover the server to which the tape drive is directly connected.

To check whether your system (hardware, operating system and backup software) is OBDR-compatible, please refer to our World Wide Web site http://www.hp.com/go/connect.

For more specific information concerning the benefits of OBDR and the latest new features please refer to our World Wide Web site http://www.hp.com/go/obdr.

If your system does not support HP One-Button Disaster Recovery, you can still use your tape drive normally to back up and restore data. However, you must remember to create a separate set of emergency recovery disks for your operating system whenever you change your system configuration.

What does HP OBDR do?

Using just the tape drive and the most recent backup cartridge HP OBDR allows you to recover from the following types of system disaster:

- Hard disk failures, as long as the replacement hard disk is the same size or larger than the original and uses the same interface (for example, replace a SCSI hard disk with another SCSI disk)
- Hardware failures where the server is replaced by an identical component
- File corruption because of an operating system error
- File corruption because of an application software error
- Viruses that prevent you from booting your system correctly
- User errors that stop you from booting your system correctly

When you run HP One-Button Disaster Recovery, your tape drive goes through the following sequence:

- 1. It goes into a special disaster recovery mode that enables it to restore your operating system and reboot. It acts like a bootable CD-ROM. (Your system's ability to boot from CD-ROM is normally enabled by default. If you have changed this setting, you will need to enable it again. Refer to your system BIOS manual for further details.)
- 2. It returns to normal tape drive mode and restores the data.

Remote disaster recovery (ProLiant servers only)

The HP Remote Insight Lights-Out Edition (RILOE) on ProLiant servers gives the IT Administrator the ability to completely recover a failed server at a remote location without physically traveling to where the server resides. The on-site non-technical person need only insert the bootable cartridge into the tape drive when asked to do so by the administrator.

Refer to the HP OBDR web site at http://www.hp.com/go/obdr for more information about using this feature and compatibility.

Testing for compatibility

We recommend that you perform a full disaster recovery immediately after installation—if possible, onto a blank hard disk. If you do not have a blank hard disk and do not want to overwrite your system, you can safely cancel the disaster recovery process at step 3 in the following procedure.

Refer to our connectivity web site (http://www.hp.com/go/connect) for more information about suitable backup applications.

Running HP OBDR

HP OBDR can only be used with backup applications that support one-button disaster recovery and methods of operating OBDR will vary between different software companies. Check our World Wide Web site (http://www.hp.com/go/obdr) for the latest information about software compatibility, firmware upgrades and troubleshooting before you use HP OBDR.

Power on the drive and insert the latest bootable cartridge in the tape drive (you may also need
to power on the server to do this). The cartridge must be written by a backup application that
writes data to tape in CD-ROM format.




Figure 25 Inserting cartridge for OBDR

2. Hold down the eject button on the tape drive and keep it pressed down while power cycling the tape drive. This activates the HP One-Button Disaster Recovery process. Release the button as soon as the LEDs flash in OBDR sequence, which is:

HP StorageWorks DAT 160 tape drives: The Ready light shows a repeated pattern of flashing-steady on-flashing.

HP StorageWorks DAT 72 and DAT 40 tape drives: The Tape light and the Clean light on the front panel flash alternately.




Figure 26 Keeping eject button pressed down, power on in OBDR model

Keyboard shortcut for HP ProLiant servers

There is no need to press the Eject button. Just power on your server and press the [F8] function key during the Power On Self Test (POST). This invokes OBDR to restore your system. For more information and specific instructions please refer to our World Wide Web site at http://www.hp.com/go/obdr.

3. Follow the on-screen instructions to set up the operating system. Normally, you can accept the default response to all the prompts, for example just press <Enter>.

- 4. The LEDs will flash in OBDR mode (as described in step 2) while the tape drive restores your operating system to a state where it can run a normal data restore.
- 5. Once the operating system has been set up and rebooted, the Tape LED display on the tape drive changes to constant green and you can remove the backup cartridge, if you wish. You are now ready to run a normal data restore. Follow the normal process for your restore application.

If restore fails

If the restore fails for any reason, refer to our World Wide Web site (http://www.hp.com/go/obdr) and do a search on OBDR for detailed troubleshooting information.

10 Diagnostic Tools and Performance

Diagnostic tools

HP Library & Tape Tools

HP StorageWorks Library & Tape Tools is the recommended diagnostic and support tool for your HP tape storage product. It is available on the CD shipped with your product or as a free download from the HP web site. It is supported on nearly all major operating systems. See http://www.hp.com/support/tapetools for compatibility information, updates and the latest version of the tool.

Troubleshooting with Library & Tape Tools

- 1. From the HP StorageWorks CD, select troubleshoot.
 - This will allow you to run Library & Tape Tools in standard mode, either directly from the CD (no installation on the server) or as an installation on your server. HP recommends installation of Library & Tape Tools, so that it can be quickly accessed at any time. HP Support will also request that you use Library & Tape Tools should you need to contact them in the future, so it is a good idea to have it installed.
- 2. When Library & Tape Tools is first run, it will scan for HP tape drives and libraries on your system and ask you to select the one to work with. At this time you can see the HBA configuration of your server, how your devices are connected and the SCSI IDs of those devices.
- Once you have selected your device you have a number of choices for troubleshooting.
 - Device identification: shows part number, serial number and information about any cartridge loaded
 - Firmware upgrade: allows you to locate and upgrade to the latest firmware. You will need to be connected to the internet for this.
 - Run tests: allows you to run proactive tests on your drive, such as the drive assessment test,
 which will verify the functionality of your drive in around 20 minutes. HP recommends
 running this test before calling HP Support. You will need to provide a 'trusted' cartridge that
 can be written to during this test.
 - Generate a support ticket: this is a full dump of the drive logs along with interpretation and
 is used by HP Support to learn about the condition of your drive. Most useful is the device
 analysis section which is the output from approximately 20 rules forming a comprehensive
 analysis of the health of your drive. These rules may give advice such as cleaning the head
 or trying a different tape if issues are found. The support ticket can be sent to HP Support
 for further analysis.
 - Run the performance tests: the tests to measure the write/read performance of your tape drive and the data generation rates of your disk subsystem are also integrated into Library & Tape Tools. Use these tests to find the performance bottleneck in your system.

Performance Assessment Tools

You can use our free, standalone performance assessment tools to check tape performance and test whether your disk subsystem can supply data at the maximum transfer rate.

The tools are located online at http://www.hp.com/support/pat along with a complete guide to understanding the performance needs of your backup system and recommendations on finding and fixing performance issues. In nearly all cases when performance is not as expected, it is the data rates of the disk subsystem that cause the bottleneck. Please follow the guide and try the tools before calling HP Support.

Note that the performance tools are also integrated into HP Library & Tape Tools, which is available both online (http://www.hp.com/support/tapetools) and on the CD-ROM supplied with your tape drive.

Optimizing performance

Various factors can affect tape drive performance, particularly in a network environment or if the drive is not on a dedicated bus.

If your tape drive is not performing as well as expected, consider the following points before contacting HP Support at http://www.hp.com/support.

- Do not put SCSI tape drives and hard disks on the same SCSI bus.
- Have you installed the correct device drivers for your operating system and backup application?
 See "Install drivers" on page 17.
- Are you backing up across a network? The network load may be affecting the speed of transfer or your backup application may only be appropriate for a single-server environment.
- Are you using the correct media for your model of tape drive? See "Use the correct media" on page 47.
- Is the backup application writing buffers at the correct speed? You may need to tune the transfer, buffer and block size settings to optimize the speed that the application writes data to the tape drive. HP StorageWorks DAT tape drives have an internal buffer of 8 MB.

11 Troubleshooting

Many users can use HP Library & Tape Tools to help them diagnose problems, see "Diagnostic tools" on page 55. We also recommend the detailed troubleshooting guide at http://www.hp.com/go/support for comprehensive troubleshooting information.

General Procedure

If a problem occurs, the first step is to try to establish whether the problem lies with the cartridge, the drive, the host computer and connections, or the way the system is being operated.

Has the system just been installed?

There could be an installation problem:

- Check through the information in the relevant installation chapter of this guide.
- 2. Check the power connectors.
- 3. Is the SCSI ID correctly set? Is there a SCSI system conflict? Has the SCSI bus been correctly terminated? See also "SCSI configuration guide" on page 63.
- 4. Check the environmental conditions against the specified limits.
- 5. Are appropriate drivers and application software installed on the host?

Are you using new cartridges or a different brand of cartridge? Have you been using the particular cartridge for a very long time?

The problem could lie with the cartridge:

- 1. Check through "Use the correct media" on page 47.
- Check that you are using a DDS-labeled cartridge—not a DAT cartridge.
- **3.** Use the correct media type, for example:
 - DAT 160 media with DAT 160 drives.
 - DAT 72 media with DAT 72 drives.
 - DDS-4 media with DAT 40 drives.

Remember that although tape drives may be able to read earlier-format media, see Table 5 on page 47, the media itself is not backward-compatible

- DAT 160 media will be ejected by all drives, other than DAT 160 drive
- 4. Has the cartridge been write-protected, see "Write-protecting cartridges" on page 48?
- Clean the tape heads with the cleaning cartridge, see "Cleaning cartridges" on page 48. Be sure to use the correct cleaning cartridge.
 - DAT 160 cleaning cartridges (C8015A) with DAT 160 tape drives.
 - Standard cleaning cartridges (C5709A) with all other HP StorageWorks DAT tape drives
- Try the operation again.
- 7. If the problem still occurs, try using a different cartridge.
- If the problem is still there, the problem probably lies with the drive or the host computer.

Has the drive been moved recently? Have any cables been disconnected and reconnected? Has the environment changed—unusually hot, cold, damp or dry? Has there been dust or dirt near the drive. Have reasonable precautions against static been taken?

The problem could lie with the drive:

- 1. Check the cables and connectors.
- 2. Clean the tape heads with the cleaning cartridge.
- 3. If the problem persists, check the environmental conditions against the specified limits (refer to http://www.hp.com). Perhaps move the drive to a more suitable site.

Has a new operating system been installed in the host computer? Has new backup software been installed?

The problem could lie with the host or the software. Consult the computer's operating manuals, the software manual, or seek help from a service engineer.

Problems with cartridges

If you experience any problems using HP branded cartridges, check:

- The cartridge case is intact and that it contains no splits, cracks or damage.
- The cartridge has been stored at the correct temperature and humidity. This prevents condensation. See the insert included with the tape cartridge for storage conditions.
- The write-protect switch is fully operational. It should move from side to side with a positive click.
- The World Wide Web site for more detailed troubleshooting information: http://www.hp.com/support.

The cartridge is jammed

If the cartridge is jammed or the backup application is unable to eject it, you can force eject the cartridge. Once the cartridge is successfully ejected, it is good practice to upgrade the firmware. If the failure occurs regularly, contact customer service at http://www.hp.com/support.

- 1. Either press and hold the Eject button on the front of the tape drive for at least 15 seconds. Or press the Eject button three times within 5 minutes.
- 2. Wait for the cartridge to be ejected. The drive waits until 35 seconds have passed from the time of the first press, to give the normal eject procedure a chance to proceed. After this period, it immediately releases the tape and ejects the cartridge, regardless of what operation it was performing. It is important that you allow sufficient time for the drive to complete this process. If you interrupt it, you may damage the media or the tape drive. The drive is then reset as though you had turned the power off and then on again.
 - You may lose data if you force eject a cartridge. The tape may also become unreadable because an EOD (End of Data) mark may not be properly written.
- 3. If the cartridge is still jammed, the tape drive has failed. Contact customer service at http://www.hp.com/support.

The drive will not accept the cartridge (or ejects it immediately)

The cartridge may have been damaged, for example dropped, or the drive may have a fault. If it is a cleaning cartridge, it has probably expired and should be discarded immediately. For data cartridges:

- 1. Check that the drive has power (the power cable is properly connected and the Tape LED is on).
- 2. Check that you are using the correct media for the tape drive, see "Use the correct media" on page 47.
- 3. Make sure that you have loaded the cartridge with the correct orientation (see "Loading and unloading" on page 45).
- 4. Check for damage to your media and discard it if it is damaged.
- 5. Use a new or known-good piece of media and see if it loads. If it does, the original cartridge is faulty and should be discarded.



12 Replacing an internal tape drive

If your tape drive proves to be faulty and cannot be repaired and it is still covered by the original warranty, it will be replaced. HP will provide a replacement tape drive free of charge. Based on availability and where geography permits, the replacement tape drive will be shipped for next business day delivery. Same day or four-hour delivery may be offered at an additional charge where geography permits. If you request HP to install the replacement tape drive, you will be charged for the travel and labor costs of this service.

To disconnect your drive

- 1. Unpack your replacement drive, and retain the packaging.
- Power off the server and any other devices that are on the same SCSI bus and disconnect from the mains power supply.
- 3. Remove the cover from the server.
- **4.** Observing normal anti-static precautions (see caution in "Attach mounting hardware" on page 22) remove any screws that are holding the tape drive in place.
- Disconnect the drive from the server's power and SCSI cables and slide it carefully out of the mounting bay.
- Put the drive into the packaging that contained the replacement drive.
- Return the faulty drive to your local HP Service Center. Instructions on where to return faulty drives will be shipped with the replacement drive.

You must ship the defective drive back to HP within a defined period of time, normally five (5) business days. The defective part must be returned with the associated documentation in the provided shipping material. Failure to return the defective part may result in HP billing you for the replacement. HP will pay all shipping and part return costs and determine the courier/carrier to be used.

P NOTE:

If you are not replacing the drive immediately, you should insert a blanking plate into the empty bay. Replace the cover on the server and secure with screws, as appropriate.

To reconnect your tape drive

Follow the step-by-step instructions in this User Guide.

13 SCSI configuration guide

SCSI in HP StorageWorks DAT devices

HP StorageWorks DAT tape drives are Ultra160 SCSI-2 compatible devices. They are designed to operate on a low voltage differential (LVD) SCSI interface. They are not compatible with high voltage differential (HVD) SCSI devices.

The drives support a burst transfer rate of 160 MB/sec. To benefit from this level of performance, it is important to ensure that the drives are connected to a SCSI bus of a similar or higher specification. This means that you need:

- An Ultra 160 or Ultra 320 SCSI host bus adapter. Ultra 2 SCSI is also supported, but performance may be degraded if there are several devices on the SCSI bus.
- LVD-rated SCSI cabling and terminators. The LVD interface enables the data to be transferred at the drive's maximum rate and provides a maximum cable length of 12 meters.

We also recommend that the tape drive is connected to a dedicated host bus adapter. If you need to connect multiple devices to the bus, performance may be restricted if there are too many (3 or more) devices on the bus that are accessed simultaneously. Connecting devices of lower SCSI specification, such as Ultra2 or Ultra SCSI, may also restrict performance to your tape drive. Using Single Ended 8-Bit SCSI devices on the same bus is not recommended, as performance will be severely impacted and complicated bus configuration is required to overcome bus termination issues.

Make sure that the last device on the SCSI bus is terminated. We recommend that you do not attach the tape drive to the same SCSI bus as the disk drive. See "SCSI termination" on page 65 for more information about terminating HP StorageWorks DAT tape drives.

SCSI terminology

SCSI is a bus interface: all the devices are connected to a single cable (some of this may be inside and some outside the host computer's case). The connection to the host itself is known as the Host Bus Adapter (HBA). You can have several HBAs in a single computer, each with its own SCSI bus: this is a common arrangement in high-performance servers. Some host bus adapters (such as the LSI Logic LSI22320-R) have more than one SCSI bus available on a single card.

Various terms are used when describing SCSI devices. These terms relate to the factors that affect performance and cable length:

- The speed of the data bus, which may be Fast, Ultra, Ultra2, Ultra3, Ultra160 or Ultra320.
- The width of the data bus, which may be Narrow or Wide (8-Bit or 16-Bit).
- The voltage level of the interface, which may be single-ended (SE) or low voltage differential (LVD).

HP StorageWorks DAT drives are Ultra 160 SCSI devices designed to operate on a low voltage differential SCSI interface.

Setting up the SCSI bus

Each device on a SCSI bus, including the SCSI host bus adapter (HBA), must be configured with a unique ID (identifier). The SCSI bus must be terminated.

NOTE:

HP recommends that a dedicated host bus adapter is used for the tape drive. A suitable adapter is available from HP as an accessory (see http://www.hp.com/go/connect.

SCSI ID numbers

For wide SCSI buses, the SCSI ID will be a number from 0 through 15, so a typical wide SCSI HBA can accommodate up to fifteen other devices. (On narrow SCSI buses, the SCSI ID is a number from 0 through 7.)

Narrow: 76543210

High — priority — Low

Wide: 7 6 5 4 3 2 1 0 15 14 13 12 11 10 9 8

Each device must have a unique SCSI ID. The drive can be assigned any unused ID between 0 and 15. Do not use SCSI ID 7, which is reserved for the SCSI controller. SCSI ID 0 is typically assigned to the boot disk and should also not be used unless the tape drive is on a dedicated SCSI bus.

SCSI ID 7 is normally reserved for the HBA because it has the highest priority on the bus. On wide buses, the priority runs from 7 (highest) to 0, then 15 down to 8 (lowest).

NOTE:

As a general rule, avoid putting tape devices on the same bus as any hard disks.

Identifying SCSI IDs

If your computer already has devices connected to the SCSI bus, you will need to know their IDs to avoid any conflict with the new tape drive. Here are some methods of finding out the information:

- The fastest and easiest way is to run HP Library & Tape Tools from this CD-ROM. HP Library & Tape Tools will check your SCSI configuration, including the SCSI controller itself and any devices currently attached to it.
- Most computers display a list of SCSI devices and IDs during the boot-up process. This usually scrolls past very fast. If you press the [Pause] key, you should be able to halt the scrolling and view the list.
- On Windows systems you can use Device Manager.
- If you have Novell NetWare installed, use its LIST DEVICES command.

If none of these is available to you, try the following sources of information:

- The details of all installed devices and settings may have been written down and stored with your computer's documentation (for new computers, this is often done by the supplier).
- Your HBA's documentation should tell you which settings it uses.
- Look at each device to find out its ID. This is usually easy with external devices. With internal
 devices, you will probably need the help of the device's documentation to identify the SCSI
 ID setting, which is usually set with jumpers.

Setting the SCSI ID on HP StorageWorks DAT drives

See the relevant chapter of this User Guide for more details. Note that host adapters check SCSI IDs only at power-on, so any changes will not take effect until the host system is power-cycled.

- On internal HP StorageWorks drives, set the SCSI ID by attaching or removing jumpers at the rear of the drive, see "Check the drive's SCSI ID" on page 19.
- On external HP StorageWorks drives, the ID is displayed on the rear panel and can be set by pressing the little buttons above and below the number (using a ball point pen), see "Check the drive's SCSI ID" on page 19.
- On removable HP StorageWorks drives, the ID is set on the back of the tape array, see "Set the drive's SCSI ID" on page 35.

SCSI termination

Terminators are essential, as they provide the correct voltages on the SCSI bus and prevent unwanted signal reflections from interfering with data transfers. The rule is:

• There must be termination at both physical ends of the bus and only at the ends.

There are two main types of termination, active and passive. Active terminators reduce interference and allow faster data throughput. On devices with high transfer speeds, such as HP StorageWorks DAT devices, active termination is required, using an LVD or multimode active terminator. (Multimode terminators allow both LVD and single-ended devices to be connected to the same bus. They detect the type of bus and automatically supply the correct termination. The terminator supplied with HP StorageWorks DAT tape drives is LVD. Multimode terminators may be used instead.)

Normally the HBA forms one end of the SCSI bus and provides termination. You only need to ensure that the other end of the bus is terminated.

Internal drives

A suitably terminated LVD internal ribbon cable is supplied with the tape drive. The terminator is usually a small, rectangular block of plastic attached to the cable end and marked 'SCSI Terminator'.




Figure 27 SCSI termination in internal drives

As long as this terminator is attached, you do not need to take any further action. However, if you have other devices attached to the cable, make sure that they have termination removed or disabled.

NOTE:

If you have an internal and external device attached to the same SCSI bus, the HBA will be in the middle of the cable and thus its termination must be disabled. See the host bus adapter's documentation for details of how to do this.

External drives

All HP StorageWorks DAT external tape drives are supplied with the appropriate cable and LVD terminators.

Make sure the terminator is firmly attached to the SCSI-OUT connector on the rear of the device when you install it. Always use the supplied LVD terminator for proper operation.




Figure 28 SCSI termination in external drives

If you have more than one device on the SCSI bus, daisy-chain them by connecting a cable from the SCSI-OUT connector on the first device to the SCSI-IN connector on the second device and make sure that the second device is terminated. (Always use an LVD-rated cable and an LVD-rated or multimode terminator.)




Figure 29 SCSI termination in daisy-chained external drives

Removable drives

For HP StorageWorks DAT removable tape drives, termination is provided by connecting a terminator to the spare SCSI connector on the rear of the tape array. There are two connectors for each bay in the tape array. It doesn't matter which is used for SCSI-IN and SCSI-OUT.

If you have each removable drive in the tape array attached to a separate bus, then, for each bay in use, you must attach a terminator to the spare connector for each device.

If you are using the removable drives to mirror backups, you can daisy-chain devices (but no more than two on each SCSI bus). Connect an LVD-rated cable from the spare SCSI connector for the first

device to one of the SCSI connectors for the second device and attach the terminator to the spare SCSI connector for the second device.

Refer to your tape array documentation for detailed instructions.

SCSI cables

Cables matter in SCSI systems. There are two factors to consider: cable length and cable quality.

Cable length

- For single-ended SCSI with Fast devices there is a maximum permissible length of 6 meters for a single SCSI bus.
- For single-ended SCSI with Ultra devices the maximum permissible length is 3 meters for four or fewer devices, and 1.5 meters for more than four devices.
- For LVD SCSI the maximum length for a single device is 25 meters. For multiple devices, the maximum combined internal/external length is 12 meters.
- If you have a combination of LVD and SE devices on the bus, the maximum cable length reverts to the SE specification. See note on SE and LVD interfaces for more information.
- For best performance, keep lengths to a minimum, but avoid very short overall lengths (less than 0.5 meters).

Cable quality

- It is important to use good quality cables. Generally speaking, cable quality affects performance and reliability. This is particularly true for external, shielded cables.
- Look after your SCSI cables. In particular, take care when connecting or disconnecting not to damage the high-density connectors. Avoid putting excessive twists in external shielded cables, as this can cause premature failure.

With internal devices

For HP StorageWorks DAT internal devices, you need a SCSI ribbon cable with the correct termination. The drives have a 68-pin wide, high-density SCSI connector. A suitable cable is supplied with the tape drive. If you are using an HP StorageWorks DAT drive on an internal bus with other peripherals that run at Ultra160 speeds, it is important that a 68-pin LVD-compatible ribbon cable is used. Do not connect your tape drive to lower-rated SCSI or to narrow SCSI.

With external devices

The cable provided with all HP StorageWorks DAT external tape drives and autoloaders will attach to a computer with a wide, very high density (VHD), LVDS SCSI connector.

If your server or host bus adapter is equipped with a high density (HD) wide SCSI connector, you will need to order a 68-pin VHD-to-HD converter or 68-pin VHD-to-HD cable. See http://www.hp.com/go/connect.

With removable devices

For HP StorageWorks DAT removable tape drives, appropriate cables and terminators are provided with the tape array.

Note on SE and LVD interfaces

SE and LVD define how the signals are transmitted along the cable.

With single-ended (SE) SCSI, each signal travels over a single wire and each signal's value is
determined by comparing the signal to a paired ground wire. Signal quality tends to decrease
over longer cable lengths or at increased signal speed.

• With low voltage differential (LVD) signaling, signals travel along two wires and the difference in voltage between the wire pairs determines the signal value. This enables faster data rates and longer cabling with less susceptibility to noise than SE signaling and reduced power consumption.

If you use LVD SCSI devices on the same bus as single-ended devices this will switch the LVD SCSI host adapter into single-ended mode and restrict cable length.

If you connect only LVD SCSI devices, the bus will operate in low voltage differential mode and Ultra 160 speeds will be enabled. You can use a combination of Ultra 160 and Ultra 2 devices. Each device will operate at its optimum speed.